




MRS SMITH

MSSW41

WALL MOUNT LUMINAIRE



-25°C

+35°C

120-277V

50/60Hz

IK08

IP65

K 5 F B-B;

Hc`Ybgi fY`a U]a i a `YZZVYbWncZH Y`
dfcXi WZfYUX`H YZ`ck]b[`]bgHfi W]cbg`
H cfc i [\ `mdf]cf`hc`]bgHJ`U]cb"

This fixture must be installed by a licensed and qualified electrician. The installer must comply with NEC and local building codes when installing the fixture

Electrical current can cause painful shock, serious injury, or even death. Make sure you turn off the power supply, ground fixture(s), and make sure all electrical connections are correct and secured

This fixture must not be installed during rain, fog, or high humidity

For use in IP65 installations.

Keep the label of the original packaging if any eventual future claims are needed

If in doubt about the symbols refer to catalog or website






Table of Contents

Packaging Contents	Pg.2
Fixture Installation	Pg.3/4/5/6/7
Maintenance / Support	Pg.8

Packaging contents



Box 14"x5"x4" @2.20lbs



Mono/Bi-Emission LED Fixture 1 ea.






Alloy Steel Cone-Point
Set Screw 2ea.




2.5 mm Allen key 1 ea.

Mud Kit 1USMK02 (Sold Separately)



Mud plate for mounting over 4"x4" J-Box.
Recommended for use with dry wall or stucco installations.

Distribution of Light




Fixture Installation


Prepare the LED fixture for Installation following these simple steps.

- The Mrs. Smith LED wall mount fixture features a 1/2" waterproof plug in the back/right side with 5/18-gauge lead conductors, this means the LED fixture will not be centered at the wall recessed J-Box when mounting.
- Identify the area with J-box where the LED fixture will be installed.
- Using the 2.5mm Allen key (included) remove the 2 set screws on the sides of the fixture, then remove the face cover from the fixture and put it aside, the fixture's face cover will be the last part to be installed.


Remove the screws on the side of the fixture



Remove the face cover and put it aside





Recessed J-Box / Feed Position




Install Led Fixture as Down Only or Up/Down

Install Led Fixture Up Only or Up/Down




Recessed J-Box / Feed Position

Make wire connections inside recessed J-Box accordingly using at least 6" of cable conductor. Insert wires through Mud Kit hole and proceed to install the Mud Kit. Run a separate conduit for 0-10v dimming if applicable.






*Connect with supplied waterproof connectors for single fixture connection runs. Not for Daisy Chained multi fixture runs.




Fixture Installation


Install the LED fixture onto the recessed J-box on the wall. Follow these steps below.




VERTICAL MOUNTING



Mud Kit has 2 holes in it, either hole can be used. (Right hole showing)




Make connections accordingly using water proof connectors





Fixture Installation Cont.

Once Mud Kit has been installed and finished, and the LED fixture has been wired, it is time to install the fixture into position. Insert the excess lead conductors into recessed J-Box along with connectors, then level the LED fixture and insert the fastening screws to secure the fixture.



After LED fixture was successfully mounted, proceed to install the face cover into fixture. Insert the face cover and press firmly and insert the 2 set screws one on each side of the fixture and tighten to complete the installation.



Maintenance

This fixture was designed and manufactured for a durable, long lasting use with minimum care. To ensure the maximum lifespan of this product, we encourage our customers to provide a quality visual inspection of the fixture and installation accessories every six months.

If there are any visible signs of issues (i.e moisture or dust) during the inspection, please clean any of the dust or moisture with a soft cloth and check to make sure that any of the fixtures are still operating normally. If there are any issues regarding the fixture please contact us as we will assist the situation at hand.

Support

Any questions, problems, or comments you have please feel free to contact our Customer Service department during our business hours Monday-Friday 8am-5pm via: Email: usaorders@targetti.com
Phone: (714) 513-1991

Visit our website: <http://www.targettiusa.com>